



| Item No | Qty | Description | Part No |
|---------|-----|-----------------------------------------------------------------|---------|
| 0 | 1 | Engine oil filter Quick Change assembly comprises items 1 – 13. | FM3301 |
| 1 | 1 | Washer | FM0002 |
| 2 | 1 | Lid lock nut | FM0005 |
| 3 | 1 | Lid compression spring | FM0006 |
| 4 | 2 | Return tube washer | FM0007 |
| 5 | 2 | Post seal | FM0008 |
| 6 | 1 | Tee handle with bleed screw | FM0001 |
| 7 | 2 | Centre tube | FM0011 |
| 8 | 1 | Element, oil | FM2000 |
| 9 | 1 | Gasket, lid | FM0004 |
| 10 | 1 | O-Ring, lid | FM0025 |
| 11 | 1 | Compression nut | FM0029 |
| 12 | 1 | Return tube - No 1 | FM0040 |
| 13 | 1 | Lid | FM0003 |